

NOTICE

Fonctionne avec :

4 piles AA non-incluses

- 1 pile AA pour le fonctionnement des aiguilles
- 3 piles AA pour la mise en marche des engrenages (purement décoratif)

Actionner le bouton on/off pour activer/arrêter la rotation des engrenages



Différents types de piles ou des piles neuves et usagées ne doivent pas être mélangés.
Les piles doivent être mises en place en respectant la polarité.
Les piles usées doivent être enlevées du produit.
Les piles doivent être mises au rebut de façon sûre. Les déposer dans des bacs de collecte prévus (renseignez-vous auprès de votre revendeur) afin de protéger l'environnement.
Different types of batteries or new and used batteries are not to be mixed.
Batteries are to be inserted with the correct polarity.
Exhausted batteries are to be removed from the product.
Batteries shall be disposed of in a safe way. Only dispose of batteries in specific collection containers (contact the your retailer for more information) in order to protect the environment.

Avertissement: les batteries ne doivent pas être exposées à une chaleur excessive telle que celle du soleil, d'un feu ou d'origine similaire.
Warning: Batteries shall not be exposed to excessive heat such as sunshine, fire or the like.