) a	LIGHT SOURCE REMOVING INSTRUCTION	Creation date (dd/mm/yyyy) :	21-Jan-22	
	X 1 QU/	ALITY	Last update date (dd/mm/yyyy) :		
1	tion	Supplier's name or trade mark	INSPIRE		
2	ıforma	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN		
3	ral in	Model Identifier - Luminaire Supplier reference	F7118XV4		
4	Gene	Light sources maker model	HT9321-12-4000K		

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	OPEN THE CLIPS BY HANDS	TICCUTES	NA
Step 2	OPEN THE LAMP COVER BY HANDS	M	NA
Step 3	TURN THE LED TUBE 90°, to remove the LED tube BY HANDS		NA
Step 4			
Step 5			
Step 6			
Step 7			
Step 8			

Step 9		
Step 10		