

^	) a	LIGHT SOURCE REMOVING INSTRUCTION	Creation date (dd/mm/yyyy) : 20/05/2021	
	Z   Q∪	ALITY	Last update date (dd/mm/yyyy) : 20/05/2021	
1	tion	Supplier's name or trade mark	INSPIRE	
2	ıforma	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS0001, 59790 RONCHIN	
3	nera	Model Identifier - Luminaire Supplier reference	Zhejiang Tai-G Photoelectric Technology Co., Ltd.	
4		Light sources maker model	W42-400MM-N, W42-600MM-N	

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	Open the end cap		Slotted screwdriver
Step 2	Cut the line between the light source and the drive		scissors
Step 3	Take out the light strip		By hand
Step 4	The light source is attached to the cover	Poddie o o o o o o o o o o o o o o o o o o o	By hand
Step 5			
Step 6			
Step 7			