





N°	DESCRIPTION	CODE N°	REMARK	QTY
1	Diverter handle	3276007370065	Chrome	1
		3276007370010	Black	
2	Thermo handle	3276007370058	Chrome	1
		1388788-002	Black	
3A	Wall fixing kit	3276007383218	Chrome	1
		3276007383225	Black	
3B	Tube bracket repair kit	3276007800760	Chrome	1
		3276007800777	Black	
4	Shower hose 150	3276007369816	Chrome	1
		3276007370089	Black	
5	Slider	3276007369847	Chrome	1
		3276007369854	Black	
6	Fixing kit	3276007369946	Chrome	1
		3276007369939	Black	
7	Handshower	3276007369830	Chrome	1
		3276007370102	Black	
8	Showerhead	3276007369861	Chrome	1
		3276007369878	Black	
9	Stop ring	3276007370072		1
10	Diverter cartridge	3276007383201		1
11	Thermo cartridge	3276007370041		1
12	Key	3276007370003		1
13	Faucet square gasket	3276007682991		1

FR Se référer au livret de garantie pour plus d'information.
ES Consulte el manual de garantía para más información.
PT Consulte o manual de garantia para mais informações.
IT Consultare il libretto di garanzia per ulteriori informazioni.
EL Ανατρέξτε στο φυλλάδιο της εγγύησης για περισσότερες πληροφορίες.
PL Patrz karcie gwarancyjnej, aby uzyskać więcej informacji.
UA Зверніться до гарантійного талону для отримання додаткової інформації.
RO Vezi broșura de garanție pentru mai multe informații.
BR Favor consultar o folheto de garantia para mais informações.
EN Refer to the warranty booklet for more information.

STUDIO

EAN: 3276007785890
 3276007785913
 3276007331899
 3276007367751

Sensea