







|   |                     |   |  |
|---|---------------------|---|--|
| 1 | General information | Supplier's name or trade mark                   | INSPIRE  |
| 2 |                     | Supplier's address                              | ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN  |
| 3 |                     | Model Identifier - Luminaire Supplier reference | <i>BD05C-YON-10-G, BD05C-YON-20-G, BD05C-YON-30-G, BD05C-YON-50-G, BD05C-YON-100-G, BD05C-YON-20-W, BD05C-YON-30-W, BD05C-YON-50-W</i> |
| 4 |                     | Light sources maker model                       | <i>BD05C-YON-10-G, BD05C-YON-20-G, BD05C-YON-30-G, BD05C-YON-50-G, BD05C-YON-100-G, BD05C-YON-20-W, BD05C-YON-30-W, BD05C-YON-50-W</i> |

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

|               | Explanation of the step   | Pictures   | Tools             |
|---------------|---|--|-------------------|
| <b>Step 1</b> | Using the cross screwdriver to remove screws securing the cover.                                    |    | Cross screwdriver |
| <b>Step 2</b> | Removing the glass plate by hand, then taking the silicone ring off.                                |    | By hand           |
| <b>Step 3</b> | Remove the reflector, then press down on the PC cover with both hands to make it fall off.          |    | By hand           |
| <b>Step 4</b> | Using an adjustable wrench to remove the connection between the waterproof connector and the shell. |   | Adjustable wrench |
| <b>Step 5</b> | Using an Allen wrench to remove the bracket.  |   | Allen wrench      |
| <b>Step 6</b> | Using a cross screwdriver to remove the light source board  |  | Cross screwdriver |