



PART LIST OF YT5452

POS	PART NUMBER	DESCRIPTION	NUM
1	PR8087-543102SB	Plunge rod	1
2	PR8105-545201SB	Feeder hopper	1
3	PR8185-545201SB	Splash guard	1
4	R8186-545201	Press bar	1
5	R8SJAB40-18B	Self tapping screw4*18	32
6	PR8006-545201Ye	Upper housing	1
7	R8SJAB50-20B	Self tapping screw5*20	24
8	R8043-545201	Switch pin	1
9	PR8313-545201-01SB	Knob	1
10	R8202-545203	Washer	4
11	PR8006-545202Ye	Lower housing	1
12	R8PA25-14D	Forelock	1
13	R8WF-05B	Washer	7
14	R8SFDD08-30D	Hexagonal screw8*30	1
15	R8WI-08B	Washer	1
16	R8301-545002	Briquet	1
17	R8206-545204	Sunk hex screw10*12	4
18	R8231-545203	Blade	2
19	R8142-545201-02	Static blade	1
20	R8301-545201	Transmission shaft	1
21	R8324-481001	Washer	8
22	R8184-545203	Dust against plate	1
23	R8087-545201-01	Pull rod	1
24	8NG-04D	Self locking nut M4	4
25	PR8020-545202WA	Reduce box upper cover	1

26	DPR8345-545201	Belt	1
27	8SJAB40-14B	Self tapping screw 4*14	4
28	R8403-545201	Helix	1
29	PR8121-545201WA	Big belt pulley	1
30	PR8121-545002WA	Eccentrik wheel	1
31	R8121-545002WA		1
31-1	R8121-545003-03	Small belt pulley	1
31-2	R8206-545202	Stator screw	2
31-3	8SJAB50-20B	Self tapping screw5*20	3
31-4	PR8020-545203WA	Reduce box lower cover	1
31-5	R8324-481001	Washer	10
31-6	R8321-481002	Washer	2
31-7	R8321-481002	Washer	2
31-8	PR8020-545201WA	Motor fornt support	1
31-9	PR8182-545201WA	Wind screen	1
31-10	R8405-545203	Stator	1
31-11	8402-545203-0000001	Rotor	1
31-12	RBC-220707-ST	627bearing	1
31-13	PR8291-481003WA	Motor rear support	1
31-14	R8406-545201	Carbon brush	2
31-15	PR8409-481002-01	Brush holder	2
31-16	R8181-481002-01	Brush holder clamp	2
31-17	8SJAB30-08B	Self tapping screw3*8	4
31-18	8NA-04D01	Hexagonal nut M4	2
32	R8292-545201-02	Support base	1
33	R8202-545203	Washer	6
34	R8087-545202-01	Fix rod	1
35	R8202-545203	Washer	2
36	R8331-543101	Support sleeve	2
37	PR8121-543101-01SE	Wheel	2
38	8NG-08D	Self locking nut M8	2
39	PR8185-543101SB	Protection sleeve	2
40	PR8086-545201SB	Plastic pin	2
41	PR8006-545203-01SE	Motor base	1
42	R8207-545201-01	Fixed nut	1
43	PR8042-545001	Switch	1
44	R8184-545204	Switch fixed board	1
45	8SJAD04-40B	Screw 4*40	2
46	PR8184-282601WA	Cable wire	1
47	PR8422-545203	Electric wire	1
48	PR8184-545001WA	Cable clamp	1
49	DPR8332-211501	Cable sleeve	1
50	PR8424-545201	Overcurrent protection	1
51	PR8042-545201-02	Switch	1
52	PR8004-545201-01SE	Motor box	1
53	PR8425-545001	Soft start	1
54	PR8181-545201SB	Dustproof board	1
55	PR8413-545201	Connecting wire 1	1
56	PR8413-545202	Connecting wire 2	1
57	PR8413-545203-01	Connecting wire 3	1
58	PR8413-545204-01	Connecting wire 4	1
59	PR8413-545205	Connecting wire	1
60	PR8413-491304	Connecting wire	2