

## ZBW50-0.08/10-24-A Parts List

NO	Designation	Qty	NO	Designation	Qty
1	<b>plug</b>	4	35	<b>bolt</b>	3
2	<b>The trim cover</b>	1	36	<b>Drain plug</b>	3
3	<b>Cover medium cover</b>	1	37	<b>Check valve</b>	1
4	<b>Self tapping screw</b>	2	38	<b>capacitance</b>	1
5	<b>Fixed power cord</b>	1	39	<b>The monkey mouth elbow</b>	1
6	<b>elbow</b>	1	40	<b>bearing 6001</b>	1
7	<b>Cylinder head</b>	1	41	<b>bearing 6203</b>	1
8	<b>Cylinder head paper pad</b>	1	42	<b>The crankshaft</b>	1
9	<b>Valve plate</b>	2	43	<b>bearing 6001</b>	1
10	<b>aluminium</b>	1	44	<b>Flat mat</b>	1
11	<b>Cylinder cushion</b>	1	45	<b>circlip</b>	1
12	<b>crankcase</b>	1	46	<b>The power cord</b>	1
13	<b>Small pulley</b>	1	47	<b>Flat mat</b>	3
14	<b>The belt</b>	1	48	<b>bolt M6*35</b>	3
15	<b>The connecting rod screws</b>	1	49	<b>hose</b>	1
16	<b>gland</b>	1	50	<b>Valve plates</b>	2
17	<b>cup</b>	1	51	<b>Grounding screw</b>	1
18	<b>Connecting rod</b>	1	52	<b>The stator</b>	1
19	<b>cylinder</b>	1	53	<b>The rotor</b>	1
20	<b>The blades</b>	1	54	<b>Carbon brush</b>	1
21	<b>Flat mat</b>	1	55	<b>bolt</b>	2
22	<b>bolt</b>	1	56	<b>bearing</b>	1
23	<b>High pressure pipe</b>	1	57	<b>Brush holder</b>	1
24	<b>Pressure relay</b>	1	58	<b>The blades</b>	1
25	<b>The connecting rod bolt</b>	1	59	<b>circlip</b>	1
26	<b>The handle</b>	1	60	<b>The trim</b>	1
27	<b>Cover the lid</b>	1	61	<b>muffler</b>	1
28	<b>bolt M6*15</b>	1	62	<b>plug</b>	1
29	<b>The handle set</b>	1	63	<b>Quick answer</b>	2
30	<b>Storage tanks</b>	1	64	<b>table</b>	1
31	<b>Handle plug</b>	4	65	<b>The pressure regulating valve</b>	1
32	<b>nut M8</b>	3	66	<b>Self tapping screw</b>	4
33	<b>Flat mat</b>	6	67	<b>switch</b>	1
34	<b>mats</b>	3			