


WX652.1

	Part No	Description	Substitute parts	Qty
1	50015124	Brush holder		2
2	50015123	Carbon Brush(pair)		1
5	50019361	Vairable Speed Board Assembly		1
7	50019362	Left/Right wind baffle		1
8	50019363	Brand label		1
9	50000737	Bearing sleeve		1
10	50003125	Bearing		1
11	50000393	Dustproof ring		1
12	50019364	Rotor		1
13	50017819	Fan		1
14	50015130	Bracket		1
15	50019365	Ball bearing		1
16	50017822	Bracket		1
17	50014851	Screw washer assembly		3
18	50001013	Washer		1
19	50002648	Screw		1
20	50017824	Brake ring		1
21	50017825	Base plate		1
22	50002833	Self tapping screw		7
23	50019366	Top cover		1

WX652.1

🗨	Part No	Description	Substitute parts	Qty
24	50002831	Self tapping screw		6
25	50017662	Bracket		1
26	50019367	Stator		1
27	50002852	Self tapping screw		2
28	50016393	Switch Cover		1
29	50016392	Switch		1
30	50002799	Self tapping screw		2
31	50017664	Press plate		1
32	50014849	Bearing		1
33	50019368	Housing		1
34	50000833	Cord clamp		1
40	50000769	O-ring		1
56	50000732	Cord Protector	50031567	1
56	50031567	Cable Protector		1
101	50019370	Rotor assembly		1
102	50019371	Bracket seat		1
104	50019372	Dust Bag		1