


RY18CS20A-125 TRONCO. 18V 1X2,5AH 20CM

5133005415 - RY18CS20A-120 - 4000475916



RYOBI

4000475916



Position	Quantité	Désignation	Référence	EAN
1001	1	VIS	5131045495	4058546430870
1002	1	ADJUSTER	5131045496	4058546430887
1008	1	HOUSSE DE PROTECTION	5131045497	4058546430894
1009	1	RONDELLE	5131037503	4002395288328
1010	1	COUVERCLE	5131045498	4058546430900
1012	1	PROTECTION D.MAINS	5131045499	4058546430917
1013	1	CIRCLIP INTERIEUR	5131037498	4002395287673
1014	1	PIGNON	5131037502	4002395288311
1015	1	AXE D'ENTRAINEMENT	5131045500	4058546430924
1016	1	MOTOR COMPLET	5131045501	4058546430931
1018	1	TRINGLE	5131045502	4058546430948
1019	1	MOTEUR	5131045503	4058546430955
1020	2	PLAQ.EN CAOUTCHOUC	5131035568	4058546149772
1023	1	POIGNEE	5131045504	4058546430962
1024	1	CLE	5131045505	4058546430979
1003	1	RAC235 GUIDE 20CM ELAGUEUR 18V	5132002589	4892210817655
1004	1	RAC270 CHAINE 20CM POUR RY18CS20A	5132005416	4892210204547