


# RBC36X26BG2-140 26CM BRUSH CUTTER IN2

5133006435 - RBC36X26BG2-140 - 4000486984



# RYOBI

4000486984



Position	Quantity	Description	Part number	EAN
1001 1	1	NUT	5131038736	4058546018894
1002 2	1	WASHER	5131033940	4002395273072
1003 3	1	WASHER	5131038735	4058546018887
1005 4	1	WASHER	5131033938	4002395273058
1006 5	3	SCREW	5131035059	4058546145743
1007 6	1	GUARD	5131035090	4058546145996
1008 7	3	NYLON LINE	5131197852	4002395139675
1010 8	1	GUARD	5131035085	4058546145941
1011 9	1	SCREW	5131035058	4058546145736
1012 10	1	SCREW	5131035057	4058546145729
1013 11	1	GEAR BOX	5131033937	4002395273041
1014 12	1	TUBE	5131035052	4058546145675
1015 13	1	WRENCH	5131038745	4058546018986
1016 14	1	WRENCH	Item discontinued(5131034510)	
1017 15	1	HOLDING PIN	5131048219	4058546543488
1018 16	1	HANDLE SET	5131035075	
1019 17	1	SCREW	5131001855	4058546083564
1020 18	2	SCREW	5131034734	4058546143275
1021 19	1	TRIGGER	5131035072	4058546145835
1022 20	1	NUT	5131001059	4058546080785
1023 21	1	SPRING	5131033932	4002395143498
1024 22	1	RETAINING PLATE	5131042594	4058546258085
1025 23	1	TRIGGER	5131035070	4058546145828
1026 24	1	SPRING	5131035071	4058546197018
1027 25	1	HANDLE SET	5131048220	4058546543495
1028 26	1	CLAMP	5131048221	4058546543501
1029 27	1	BAND	5131035095	4058546146030
1030 28	1	TERMINAL PLUG	Item discontinued(5131041271)	
1031 29	1	SCREW	5131034780	4058546143510
1032 30	22	SCREW	5131035877	4058546152673
1033 31	1	HOUSING	5131048222	4058546543518
1034 32	1	HOUSING	5131048223	4058546543525
1035 33	1	HOUSING	5131035051	4058546145668
1036 34	1	MOTOR	5131041267	4058546065317
1037 35	1	CONNECTOR	5131035042	4058546145576
1039 36	1	WIRE	5131035106	4058546197032
1004 37	1	RAC117 TRI-ARC BLADE 26CM EMEA	5132002668	4892210819734
1009 38	1	RAC114 36V BRUSHCUTTER SPOOL	5132002669	4892210819727