





N°	DESCRIPTION	EAN CODE	REMARK	QTY
1	Diverter handle	3276007369984	Chrome	1
		3276007369991	Black	
2	Mixer handle	3276007370027	Chrome	1
		3276007369977	Black	
3A	Wall fixing kit	3276007383218	Chrome	1
		3276007383225	Black	
3B	Tube bracket repair kit	3276007800760	Chrome	1
		3276007800777	Black	
4	Shower hose 150	3276007369816	Chrome	1
		3276007370089	Black	
5	Slider	3276007369847	Chrome	1
		3276007369854	Black	
6	Fixing kit	3276007369946	Chrome	1
		3276007369939	Black	
7	Handshower	3276007369830	Chrome	1
		3276007369878	Black	
8	Showerhead	3276007369861	Chrome	1
		3276007370102	Black	
9	Diverter cartridge	3276007383195		1
10	Mixer cartridge	3276007369922		1
11	Faucet square gasket	3276007682991		1

FR Se référer au livret de garantie pour plus d'information.
ES Consulte el manual de garantía para más información.
PT Consulte o manual de garantia para mais informações.
IT Consultare il libretto di garanzia per ulteriori informazioni.
EL Ανατρέξτε στο φυλλάδιο της εγγύησης για περισσότερες πληροφορίες.
PL Patrz karcie gwarancyjnej, aby uzyskać więcej informacji.
UA Зверніться до гарантійного талону для отримання додаткової інформації.
RO Vezi broșura de garanție pentru mai multe informații.
BR Favor consultar o folheto de garantia para mais informações.
EN Refer to the warranty booklet for more information.

STUDIO

EAN: 3276007785883
 3276007785906
 3276007331882
 3276007367744

Sensea