

SPARE PART FILE

Petrol Lawnmower


PLM3-56Z200.6

3276007940084



STERWINS

MACHINE PART



PLM3-56Z200.6
3276007940084

Identification Number of the Exploded view	Supplier Internal reference	Name of the part
1	2105300159A	Blade fastening bolt
2	2105300001C	Dished washer
3	2105200367A	Friction tool holder pressure plate
4	21052004082000A	blade
5	2105500009A	blade support
6	2105400051A	blade holder bushing
7	2109100273A	Grass baffle
8	2109300249A	Hexagon socket set screw with cylindrical end
9	21031005570082A	Driving pulley
10	2102600014A	V-belt
11	30512050035000	Large washer
12	30313090055000	Hexagon lock nut
13	2107200064B	Straw bag bracket
14	3011301006	Self tapping screw
15	21041001930001D	Belt protection cover
16	3031309002	Hexagon lock nut
17	3051303001	Flat washer
18	21041001940120N	Head mask
19	21011004380120A	8 "wheel cover
20	21011004390123A	8 "wheel cover pressure plate
21	30323060035000	Hexagon flange locking nut
22	A26800401501	bearing
23	21011006400001A	8-inch wheel assembly
24	21011006410001A	Dust wheel cover
25	3011301010	Self tapping screw
26	A26800705102	Flat gasket
27	3091308003	Hexagon flange bolt
28	21011005550001A	Wheel axle lower seat
29	2101300254A	Front axle assembly
30	2101800009A	Shock absorber spring
31	21011005540001A	Wheel axle upper seat
32	30313090035000	Hexagon lock nut
33	2109800053C	Front wheel axle tension spring
34	21011004360120A	11 "wheel cover
35	21011004370123A	11 "wheel cover pressure plate
36	21011004040001A	Wheel Assembly
37	2101100081B	Wheel ring gear
38	21011003730001F	11 "Dust wheel cover
39	21041001470001N	Bumper
40	30113010265000	Self tapping screw
41	2103200303B	connecting rod
42	21031000230020D	Clean the joint
43	2109100013N	O-ring
44	A26800705001	wave washer
45	2109600021A	Plug
46	21035001570214A	Mower disc assembly
47	21062011205007A	Gear plate
48	30913070165000	Hexagon flange bolt
49	3043301001	Open retaining ring
50	2104400013E	Left output gear assembly
51	21011004410001A	Cushion block
52	30213020045000	Machine tooth screw
53	21011004420120B	Rear axle sleeve







Identification Number of the Exploded view	Supplier Internal reference	Name of the part
54	30323060015000	All metal hexagonal flange locking nut
55	3082301003	Cylindrical pin
56	21023001785011A	Transmission assembly
57	2104400014E	Right output gear assembly
58	30913050015000	Hexagon flange bolt
59	2109200090A	Limit plate
60	2102300181A	Positioning plate
61	2103200229A	Lock block
62	2103800011A	Lock block torsion spring
63	2103300040A	Lock block fixed shaft
64	3043301003	Open retaining ring
65	2103200228A	Side row fixing plate
66	3052301004	Spring washer
67	3021302002	Machine tooth screw
68	2106200053N	Side row positioning shaft
69	2109800066D	Side cover plate torsion spring
70	21061001203204A	Side row cover plate
71	21041007570001B	Side row protective cover
72	21041001163206A	Lock button pressing plate
73	2109800022C	spring
74	21041001150020A	Insert lock button
75	21061006910001A	Grass crushing plugin
76	A26800203001A	Cross recessed pan head screws
77	2106500005B	Handle fixing plate
78	2101500244A	Rear wheel axle assembly
79	2106800649A	Adjusting the torsion spring
80	3081301001	Split pin
81	A26800710001	Flat washer
82	2106500004A	Adjusting the height lever
83	21061006083219A	Adjusting the handle assembly
84	A26800201801	Machine tooth screw
85	21033000660001B	Right handle bracket
86	2109800118C	Right-handed torsion spring
87	2106300250A	Long rod
88	2109800117C	Left-handed torsion spring
89	21033000650001B	Left handle bracket
90	21077001312173A	Straw collecting bag
91	2109900067A	Special bolts
92	2109900066A	Triangle self tapping bolt
93	2100X04713	Rear cover plate assembly
94	2030100386A	Gasoline engine assembly
95	2106300251A	Special hexagonal bolt
96	2106300189A	Shaft sleeve
97	2106300258A	Cylindrical pin
98	21041007290020B	Locking knob
99	2106300166A	Shaft sleeve
100	2109800200A	Lower handlespring
101	2106300335A	Pin
102	3091307003	Hexagon flange bolt
103	21063000025007A	Hanging hook
104	3051303003	Flat washer
105	3052301003	Spring washer
106	A26800501603A	Cap nut







Identification Number of the Exploded view	Supplier Internal reference	Name of the part
107	21061000013201A	Wire clamp
108	21063002140214A	Lower armrest
109	21061006670001A	Lower adjustment gear
110	2109300058A	Self tapping screw
111	21061006500020A	Locking handle
112	21093000635007A	Cylindrical pin
113	2109200025A	Compression plate
114	2109300069A	Locking handle bolt
115	21061006660001A	Upper adjustment gear
116	30313060025000	Hexagon nut
117	21061005920001B	knob
118	21061000043201A	Cable fixing block
119	2106800638A	Drive cable assembly
120	2109800281A	Flameout cable assembly
121	2106800829A	Accelerator handle combination
122	30913070135000	Hexagon flange bolt
123	21041011800001A	rod fixing block
124	21063002130001A	Upper armrest
125	21063005170020A	Flameout lever
126	21063002170001A	Drive rod
127	2106100321A	handlecover
128	21071000730001N	Grass basket handle
129	3011301004	Self tapping screw
130	21071000080020A	Windshield
131	21071001530120A	Grass basket cover plate
132	3011301005	Self tapping screw







Spare part n°	Spare part Reference Or KIT reference	KIT or SPARE PART **		Description	Piece number (related to the exploded view)
1	K-1-51B150.5-10	KIT	K	SP - MULCHING ACCESSORIES	25,72,73,74,75
2	K-2-46Z150A.6-9	KIT	K	SP - FRONT WHEEL KIT	19,20,21,22,23,24,25,26
3	K-3-56B150.5-3	SPARE PART	S	SP - BELT	10
4	K-3-56B150.5-4	KIT	K	SP - SELF-PROPELLED GEARBOX ASSEMBLY	26,49,50,51,52,53,54,55,56,57,58,59,60
5	K-3-56B190-1	SPARE PART	S	SP - GRASS CATCHER	90
6	K-3-56B190-2	KIT	K	SP - GRASS BAG ASSEMBLY	13,128,129,130,131,132
7	K-3-56B190-29	KIT	K	SP - FRONT HOUSING	14,18
8	K-3-56B190-3	SPARE PART	S	SP - BLADE	4
9	K-3-56B190-4	KIT	K	SP - BLADE SUPPORT KIT	1,2,3,5,6
10	K-3-56B190-8	KIT	K	SP - SIDE DISCHARGE KIT	61,62,63,64,65,66,67,68,69,70,71
11	K-3-56Z200.6-24	KIT	K	SP - BELT PROTECTOR KIT	14,15,16,17
12	K-3-56Z200.6-25	KIT	K	SP - FRONT WHEEL SHAFT ASSEMBLY	27,28,29,30,31,32,33
13	K-3-56Z200.6-29	KIT	K	SP - UPPER HANDLEBAR	110,115,124,127
14	K-3-56Z200.6-30	SPARE PART	S	SP - FLAMEOUT DRAGLINE ASSY	120
15	K-3-56Z200.6-31	SPARE PART	S	SP - FLAMEOUT ROD KIT	125
16	K-3-56Z200.6-32	KIT	K	SP - BACK COVER KIT	32,86,87,88,93
17	K-3-5B150.5-4	KIT	K	SP - REAR WHEEL AXLE KIT	32,76,77,78,79,80,81,82,83,84
18	K-3-5B150.5-6	SPARE PART	S	SP - DRIVING CABLE	119
19	KIT-PLM2-27	KIT	K	SP - REAR WHEEL KIT	21,22,25,26,34,35,36,37,38
20	KIT-PLM2-33	KIT	K	SP - LEFT BRACKET	21,48,89
21	KIT-PLM2-34	KIT	K	SP - RIGHT BRACKET	21,48,85
22	KIT-PLM2-37	SPARE PART	S	SP - HEIGHT ADJUSTING PLATE	47
23	KIT-PLM3-28	KIT	K	SP - LOWER HANDLEBAR	97,98,99,100,101,108,109,110
24	KIT-PLM3-32	KIT	K	SP - LOWER KNOB	16,95,96
25	KIT-PLM3-36	SPARE PART	S	SP - DRIVING ROD	126
26	PLM-12	SPARE PART	S	SP - BEARINGS	22
27	PLM-21	KIT	K	SP - ADJUST KNOB KIT	17,111,112,113,114,116,117
28	PLM-23	KIT	K	SP - WATER NOZZLE KIT	42,43
29	PLM-26	SPARE PART	S	SP - CLAMP CABLE KIT	107
30	KIT-PLM2-38	KIT	K	SP - STARTER ROPE'S HOOK	102,103,104,105,106



** The difference between a KIT and a SPARE PART is the quantity of component included in :

from 2 components it's a kit
SPARE PART means, only 1 component, it's only a spare part (ex : Spear it's a spare part)


KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
1	K-1-51B150.5-10	SP - MULCHING	25,72,73,74,75	6
		Identification Number of	Name of the part	Quantity
		25	Self tapping screw	2
		72	Lock button pressing plate	1
		73	spring	1
		74	Insert lock button	1
		75	Grass crushing plugin	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
2	K-2-46Z150A.6-9	SP - FRONT WHEEL	19,20,21,22,23,24,25,26	11
		Identification Number of	Name of the part	Quantity
		19	8 "wheel cover	1
		20	8 "wheel cover pressure plate	1
		21	Hexagon flange locking nut	1
		22	bearing	2
		23	8-inch wheel assembly	1
		24	Dust wheel cover	1
		25	Self tapping screw	3
		26	Flat gasket	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
4	K-3-56B150.5-4	SP - SELF-PROPELLED	26,49,50,51,52,53,54,55,56,57,58,59,6	29
		Identification Number of	Name of the part	Quantity
		26	Flat gasket	4
		49	Open retaining ring	4
		50	Left output gear assembly	1
		51	Cushion block	2
		52	Machine tooth screw	4
		53	Rear axle sleeve	2
		54	All metal hexagonal flange locking nut	4
		55	Cylindrical pin	2
		56	Transmission assembly	1
		57	Right output gear assembly	1
		58	Hexagon flange bolt	2
		59	Limit plate	1
		60	Positioning plate	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
6	K-3-56B190-2	SP - GRASS BAG	13,128,129,130,131,132	7
		Identification Number of	Name of the part	Quantity
		13	Straw bag bracket	1
		128	Grass basket handle	1
		129	Self tapping screw	1
		130	Windshield	1
		131	Grass basket cover plate	1
		132	Self tapping screw	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
7	K-3-56B190-29	SP - FRONT HOUSING	14,18	11
		Identification Number of	Name of the part	Quantity
		14	Self tapping screw	10
		18	Head mask	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
9	K-3-56B190-4	SP - BLADE SUPPORT	1,2,3,5,6	5
		Identification Number of	Name of the part	Quantity
		1	Blade fastening bolt	1
		2	Dished washer	1
		3	Friction tool holder pressure plate	1
		5	blade support	1
		6	blade holder bushing	1

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
10	K-3-56B190-8	SP - SIDE DISCHARGE	61,62,63,64,65,66,67,68,69,70,71	13
		Identification Number of	Name of the part	Quantity
		61	Lock block	1
		62	Lock block torsion spring	1
		63	Lock block fixed shaft	1
		64	Open retaining ring	1
		65	Side row fixing plate	1
		66	Spring washer	2
		67	Machine tooth screw	2
		68	Side row positioning shaft	1
		69	Side cover plate torsion spring	1
		70	Side row cover plate	1
		71	Side row protective cover	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
11	K-3-56Z200.6-24	SP - BELT	14,15,16,17	7
		Identification Number of	Name of the part	Quantity
		14	Self tapping screw	2
		15	Belt protection cover	1
		16	Hexagon lock nut	2
		17	Flat washer	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
12	K-3-56Z200.6-25	SP - FRONT WHEEL	27,28,29,30,31,32,33	17
		Identification Number of	Name of the part	Quantity
		27	Hexagon flange bolt	4
		28	Wheel axle lower seat	2
		29	Front axle assembly	1
		30	Shock absorber spring	2
		31	Wheel axle upper seat	2
		32	Hexagon lock nut	4
		33	Front wheel axle tension spring	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
13	K-3-56Z200.6-29	SP - UPPER	110,115,124,127	8
		Identification Number of	Name of the part	Quantity
		110	Self tapping screw	4
		115	Upper adjustment gear	2
		124	Upper armrest	1
		127	handlecover	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
16	K-3-56Z200.6-32	SP - BACK COVER KIT	32,86,87,88,93	6
		Identification Number of	Name of the part	Quantity
		32	Hexagon lock nut	2
		86	Right-handed torsion spring	1
		87	Long rod	1
		88	Left-handed torsion spring	1
		93	Rear cover plate assembly	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
17	K-3-5B150.5-4	SP - REAR WHEEL	32,76,77,78,79,80,81,82,83,84	12
		Identification Number of	Name of the part	Quantity
		32	Hexagon lock nut	2
		76	Cross recessed pan head screws	2
		77	Handle fixing plate	1
		78	Rear wheel axle assembly	1
		79	Adjusting the torsion spring	1
		80	Split pin	1
		81	Flat washer	1
		82	Adjusting the height lever	1
		83	Adjusting the handle assembly	1
		84	Machine tooth screw	1

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
19	KIT-PLM2-27	SP - REAR WHEEL KIT	21,22,25,26,34,35,36,37,38	15
		Identification Number of	Name of the part	Quantity
		21	Hexagon flange locking nut	1
		22	bearing	2
		25	Self tapping screw	6
		26	Flat gasket	1
		34	11 "wheel cover	1
		35	11 "wheel cover pressure plate	1
		36	Wheel Assembly	1
		37	Wheel ring gear	1
		38	11 "Dust wheel cover	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
20	KIT-PLM2-33	SP - LEFT BRACKET	21,48,89	5
		Identification Number of	Name of the part	Quantity
		21	Hexagon flange locking nut	2
		48	Hexagon flange bolt	2
		89	Left handle bracket	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
21	KIT-PLM2-34	SP - RIGHT BRACKET	21,48,85	5
		Identification Number of	Name of the part	Quantity
		21	Hexagon flange locking nut	2
		48	Hexagon flange bolt	2
		85	Right handle bracket	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
23	KIT-PLM3-28	SP - LOWER	97,98,99,100,101,108,109,110	17
		Identification Number of	Name of the part	Quantity
		97	Cylindrical pin	2
		98	Locking knob	2
		99	Shaft sleeve	2
		100	Lower handlespring	2
		101	Pin	2
		108	Lower armrest	1
		109	Lower adjustment gear	2
		110	Self tapping screw	4
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
24	KIT-PLM3-32	SP - LOWER KNOB	16,95,96	6
		Identification Number of	Name of the part	Quantity
		16	Hexagon lock nut	2
		95	Special hexagonal bolt	2
		96	Shaft sleeve	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
27	PLM-21	SP - ADJUST KNOB KIT	17,111,112,113,114,116,117	14
		Identification Number of	Name of the part	Quantity
		17	Flat washer	2
		111	Locking handle	2
		112	Cylindrical pin	2
		113	Compression plate	2
		114	Locking handle bolt	2
		116	Hexagon nut	2
		117	knob	2

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
28	PLM-23	SP - WATER NOZZLE	42,43	2
		Identification Number of	Name of the part	Quantity
		42	Clean the joint	1
		43	O-ring	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
30	KIT-PLM2-38	SP - STARTER ROPE'S	102,103,104,105,106	5
		Identification Number of	Name of the part	Quantity
		102	Hexagon flange bolt	1
		103	Hanging hook	1
		104	Flat washer	1
		105	Spring washer	1
		106	Cap nut	1

MOTOR PART



Identification Number of the Exploded view	Supplier Internal reference	Name of the part
1	100011262-0004	Bolt, M6×14
2	100002308	Valve Cover
3	100030069	Gasket, Valve Cover
4	100004421	Rocker Arm Assembly
5	100004580	Valve Spring Seat
6	100004565	Valve Spring
7	100004598	Intake Valve Seal
8	100004523	Intake Valve
9	100004547	Exhaust Valve
10	100063679	Rocker Arm Base
11	100002461-0002	Bolt, M8×54
12	100066426	Cylinder Head
13	100011452-0010	Nut, M6
14	100006850-0001	Muffler Guard
15	100006262	Muffler
16	100011261-0014	Bolt, M6×12
17	100006523	Gasket, Muffler
18	100010346-0001	Stud, M6×95
19	100009378	Spark Plug
20	100010348-0001	Stud, M6×87
21	100053668	Gasket, Carburetor Insulator
22	100005603	Insulator
23	100005928	Gasket, Carburetor
24	100005380-0001	Carburetor
25	100005946	Gasket, Air Filter
26	100004649	Air Filter Assembly
27	100008035	Choke Lever
28	100005031	Air Filter Base Assembly
29	100004834	Air Filter Cover
30	100004759	Air Filter Element
31	100011270-0007	Bolt, M6×30
32	100011463-0003	Nut, M6
33	100010205	Gasket, Cylinder Head
34	100010558	Pin, φ10×16
35	100066141	Push Rod
36	100004262	Tappet
37	100003245	Piston Ring Set
38	100003221	Circlip
39	100003125	Piston Pin
40	100003080	Piston
41	100030472	Connecting Rod Assembly
42	100008763-0002	Fuel Cap
43	100008880	Lock Nut
44	100008662	Damping Pad
45	100008936	Damping Pad
46	100008686-0001	Fuel Tank
47	100008663	Gasket, Fuel Tank
48	100009020	Fuel Filter
49	100005136	Clamp
50	100017750-0001	Fuel Hose φ6.3×φ12.5×322
51	100055666	Governor Spring
52	100007602-0001	Blower Housing
53	100007217-0004	Recoil Starter
54	100007668	Inner Shroud
55	100010302-0001	Stud, M6×78.5






Identification Number of the Exploded view	Supplier Internal reference	Name of the part
56	100010303-0001	Stud, M6×74
57	100011462-0002	Nut, M14×1.5
58	100009494	Flywheel
59	100017640	Oil Seal, φ22×φ35×6
60	100004053-0001	Breather Cover
61	100010260	Gasket, Oil Filter
62	100008440	One-way Valve Spring
63	100004065	Breather Filter Screen
64	100140934	Breather Valve
65	100011266-0010	Bolt, M6×20
66	100000656	Clip
67	100030058-0002	Ignition Module
68	100011271-0006	Bolt, M6×35
69	100086238	Brake Guard
70	100009646	Brake Spring
71	100009615-0002	Brake Assembly
72	100007137-0001	Shield
73	100073318	Crankcase
74	100053669	Gasket, Crankcase
75	100010544	Pin, φ7×14
76	100010554	Pin, φ9×14
77	100010680	Bearing, 6205
78	100750105	Crankshaft
79	100010577	Woodruff Key
80	100004118-0001	Dipstick
81	100004142	O-Ring, Dipstick
82	100004141	O-Ring, Dipstick
83	100010527-0001	Washer, φ25.4×1×φ34
84	100017643	Oil Seal, φ25×φ40×7
85	100002993	Crankcase Cover
86	100011269-0010	Bolt, M6×28
87	100010272-0001	Earth Bolt
88	100010459	Washer, φ10×1.5×φ16
89	100008451	Governor Gear Mounting Plate
90	100008293	Governor Gear
91	100054825	Camshaft
92	100000655	Clip
93	100002858	Breather Hose
94	100059066	Idle Spring
95	100007955	Throttle Linkage
96	100000671	Clip
97	100050590-0001	Governor Gear Bracket Assembly
98	100007971	Governor Gear Shaft
99	100017630	Oil Seal, φ6×φ11×4
100	100007986	Cotter Pin
101	100054663-0001	Governor Lever
102	100000121-0003	Spark Plug Socket






Spare part n°	Spare part Reference Or KIT reference	KIT or SPARE PART **		Description	Piece number (related to the exploded view)
31	K-3-56Z200.6-1	KIT	K	Cylinder head cover assembly	1,2,3
32	K-3-56Z200.6-3	KIT	K	muffler assembly	13,14,15,17,18
33	K-3-56Z200.6-10	KIT	K	launcher component	32,53
34	K-3-56Z200.6-12	KIT	K	flywheel assembly	57,58
35	K-3-56Z200.6-16	KIT	K	brake components	70,71
36	K-3-56Z200.6-18	KIT	K	oil dipstick assembly	68,80,81,82
37	K-3-56Z200.6-14	KIT	K	igniter assembly	65,66,67
38	K-3-56Z200.6-4	KIT	K	Heat shield assembly	20,21,22
39	K-3-56Z200.6-5	KIT	K	Carburetor Assembly	23,24,25
40	K-3-56Z200.6-6	KIT	K	air filter assembly	26,30,31,32
41	K-1-46Z150.6-15	KIT	K	Oil drain bolt assembly	87,88
42	K-3-56Z200.6-20	KIT	K	Throttle bracket assembly	94,95,101
43	K-3-56Z200.6-21	KIT	K	Throttle control components	1,97
44	K-3-56Z200.6-8	KIT	K	fuel tank assembly	46,47,48
45	K-1-46Z150.6-20	SPARE PART	S	Spark plug sleeve assembly	102
46	K-3-56Z200.6-7	KIT	K	fuel tank cap assembly	42,43,44,45
47	K-3-56Z200.6-9	KIT	K	Tubing components	49,50
48	K-3-56Z200.6-11	KIT	K	Air guide inner cover assembly	54,55,56
49	K-3-56Z200.6-13	KIT	K	filter cover assembly	1,60,61,62,63,64
50	K-3-56Z200.6-17	KIT	K	windshield assembly	16,72
51	K-3-56Z200.6-19	KIT	K	Line Card B Components	16,92
52	K-3-56Z200.6-22	KIT	K	Tension spring and cotter pin assembly	51,100
53	K-3-56Z200.6-2	KIT	K	valve spring assembly	5,6
54	K-3-56Z200.6-15	KIT	K	Flywheel fender assembly	68,69





** The difference between a KIT and a SPARE PART is the quantity of component included in :
KIT means, several component,





from 2 components it's a kit

SPARE PART means, only 1 component, it's only a spare part (ex : Spear it's a spare part)

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
31	K-3-56Z200.6-1	Cylinder head cover	1,2,3	6
		Identification Number of	Name of the part	Quantity
		1	Bolt, M6×14	4
		2	Valve Cover	1
		3	Gasket, Valve Cover	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
32	K-3-56Z200.6-3	muffler assembly	13,14,15,17,18	7
		Identification Number of	Name of the part	Quantity
		13	Nut, M6	2
		14	Muffler Guard	1
		15	Muffler	1
		17	Gasket, Muffler	1
		18	Stud, M6×95	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
33	K-3-56Z200.6-10	Launcher component	32,53	4
		Identification Number of	Name of the part	Quantity
		32	Nut, M6	3
		53	Recoil Starter	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
34	K-3-56Z200.6-12	flywheel assembly	57,58	2
		Identification Number of	Name of the part	Quantity
		57	Nut, M14×1.5	1
		58	Flywheel	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
35	K-3-56Z200.6-16	brake components	70,71	2
		Identification Number of	Name of the part	Quantity
		70	Brake Spring	1
		71	Brake Assembly	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
36	K-3-56Z200.6-18	oil dipstick assembly	68,80,81,82	4
		Identification Number of	Name of the part	Quantity
		68	Bolt, M6×35	1
		80	Dipstick	1
		81	O-Ring, Dipstick	1
		82	O-Ring, Dipstick	1

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
37	K-3-56Z200.6-14	igniter assembly	65,66,67	3
		Identification Number of	Name of the part	Quantity
		65	Bolt, M6×20	1
		66	Clip	1
		67	Ignition Module	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
38	K-3-56Z200.6-4	Heat shield assembly	20,21,22	4
		Identification Number of	Name of the part	Quantity
		20	Stud, M6×87	2
		21	Gasket, Carburetor Insulator	1
		22	Insulator	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
39	K-3-56Z200.6-5	Carburetor Assembly	23,24,25	3
		Identification Number of	Name of the part	Quantity
		23	Gasket, Carburetor	1
		24	Carburetor	1
		25	Gasket, Air Filter	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
40	K-3-56Z200.6-6	air filter assembly	26,30,31,32	5
		Identification Number of	Name of the part	Quantity
		26	Air Filter Assembly	1
		30	Air Filter Element	1
		31	Bolt, M6×30	1
		32	Nut, M6	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
41	K-1-46Z150.6-15	Oil drain bolt assembly	87,88	2
		Identification Number of	Name of the part	Quantity
		87	Earth Bolt	1
		88	Washer, φ10×1.5×φ16	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
42	K-3-56Z200.6-20	Throttle bracket	94,95,101	3
		Identification Number of	Name of the part	Quantity
		94	Idle Spring	1
		95	Throttle Linkage	1
		101	Governor Lever	1

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
43	K-3-56Z200.6-21	Throttle control	1,97	2
		Identification Number of	Name of the part	Quantity
		1	Bolt, M6×14	1
		97	Governor Gear Bracket Assembly	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
44	K-3-56Z200.6-8	fuel tank assembly	46,47,48	4
		Identification Number of	Name of the part	Quantity
		46	Fuel Tank	1
		47	Gasket, Fuel Tank	2
		48	Fuel Filter	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
45	K-1-46Z150.6-20	Spark plug sleeve	102	1
		Identification Number of	Name of the part	Quantity
		102	Spark Plug Socket	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
46	K-3-56Z200.6-7	fuel tank cap assembly	42,43,44,45	4
		Identification Number of	Name of the part	Quantity
		42	Fuel Cap	1
		43	Lock Nut	1
		44	Damping Pad	1
		45	Damping Pad	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
47	K-3-56Z200.6-9	Tubing components	49,50	3
		Identification Number of	Name of the part	Quantity
		49	Clamp	2
		50	Fuel Hose $\phi 6.3 \times \phi 12.5 \times 322$	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
48	K-3-56Z200.6-11	Air guide inner cover	54,55,56	4
		Identification Number of	Name of the part	Quantity
		54	Inner Shroud	1
		55	Stud, M6×78.5	2
		56	Stud, M6×74	1

KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
49	K-3-56Z200.6-13	filter cover assembly	1,60,61,62,63,64	7
		Identification Number of	Name of the part	Quantity
		1	Bolt, M6×14	2
		60	Breather Cover	1
		61	Gasket, Oil Filter	1
		62	One-way Valve Spring	1
		63	Breather Filter Screen	1
		64	Breather Valve	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
50	K-3-56Z200.6-17	windshield assembly	16,72	3
		Identification Number of	Name of the part	Quantity
		16	Bolt, M6×12	2
		72	Shield	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
51	K-3-56Z200.6-19	Line Card B Components	16,92	2
		Identification Number of	Name of the part	Quantity
		16	Bolt, M6×12	1
		92	Clip	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
52	K-3-56Z200.6-22	Tension spring and	51 ,100	2
		Identification Number of	Name of the part	Quantity
		51	Governor Spring	1
		100	Cotter Pin	1
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
53	K-3-56Z200.6-2	valve spring assembly	5,6	4
		Identification Number of	Name of the part	Quantity
		5	Valve Spring Seat	2
		6	Valve Spring	2
KIT n°	Spare part Reference	Description	Piece number (related to the exploded view)	Component on the
54	K-3-56Z200.6-15	Flywheel fender	68,69	3
		Identification Number of	Name of the part	Quantity
		68	Bolt, M6×35	2
		69	Brake Guard	1