LIGHT SOURCE REMOVING INSTRUCTION			Creation date (dd/mm/yyyy) : 15/09/2022	
			Last update date (dd/mm/yyyy) : 15/09/2022	
1	tion	Supplier's name or trade mark	INSPIRE	
2	forma	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN	
3	ral int	Model Identifier - Luminaire Supplier reference	DL-GP3AC10HR1-2	
4	Gene	Light sources maker model	DL-GP3AC10HR1-2	

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	Use a Sucker cup to suck up the diffuser, remove the diffuser		Sucker
Step 2	Hold the power cord with tweezers and open the power cord with electric soldering iron		electric soldering iron, pincette
Step 3	Remove the light source plate by turning the screw counterclockwise with a $\Phi 5$ cross screwdriver		A φ5 cross screwdriver
Step 4	Remove the drive assembly by turning the screw counterclockwise with a $\Phi 5$ cross screwdriver	The state of the s	A φ5 cross screwdriver
Step 5	light source		By hand
Step 8			
Step 9			
Step 10			