		des.	Creation date (dd/mm/yyyy) :	08/08/2023
		PRODUCT INFORMATION SHEET (ANNEX 5)	Last update date (dd/mm/yyyy) :	08/08/2023
1	ч	Supplier's name or trade mark	ADEO Services	
2	rmatic	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CSO0001	, 59790 RONCHIN
3	al info	Model Identifier - Luminaire Supplier reference	T058-T06K1-BN2-S	
4	Genera	Light sources maker model	T058-T06K1-WN2-S-LS	
5		Date of placement on the market	24/09/2023	
6	:96	Lighting technology used:	LED	
7		Light source can type (or other electric interface)	/	
. 8		Non-directional (NDLS) or directional (DLS):	, NDLS	
9		Mains (MLS) or non-mains (NMLS):	NMLS	
10	sour	Connected light source (CLS):	по	
11	light	Colour-tuneable light source:	no	
12	pe of	Finelone:	no	
13	T	High luminance light source.	no	
14		Anti-glare shield:	no	
15		Dimmahle:	only with specific dimmers	
16		Energy consumption in on-mode (kWh/1000 h)	4	KWh/1000h
17		Fnergy efficiency class	D	
18	-	Useful luminous flux ( <b>Φuse</b> ), indicating if it refers to the flux in	5501m	360
19		a sphere (360°), in a wide cone (120°) or in a narrow cone (90°),	stans	300
20		Correlated colour temperature, rounded to the nearest 100 K, or the	2700/4000	ĸ
20		range of correlated colour temperatures, rounded to the nearest 100 K,	2 2	w
21	ers:	On mode power (1 <sub>co</sub> ), expressed in w and rounded to the first decimal	0.00	w
22		Networked standby power (Pnet) for CLS, expressed in W and rounded to	0.00	w
23	parame	the second decimal Colour rendering index, rounded to the nearest integer, or the range	90	n
24	duct ]	of CRI-values that can be set Outer dimensions without separate control gear, lighting control parts	00	
20	al pro	and nonlighting control parts, if any (millimetre)		
20	Genera	neigni (mm)		·····
21			150.00	
28		Depth (mm) Spectral power distribution in the range 250 nm to 800 nm, at full-	46. 00	mm
29		load (insert picture of the spectral power distribution + name of picture+extension (.jpeg)	T058-T06K1-BN2-S-spectral po	wer distribution.jpg
30		Claim of equivalent power	yes	
31		If yes, equivalent power (W)	45	W
32		Chromaticity coordinates (x and y)	0.380; 0.380	
33	eters ional ht ces:	Peak luminous intensity (cd)		cd
34	Parame direct lig sourc	Beam angle in degrees (no decimal), or the range of beam angles that can be set		Degrees
35	for ED :es:	R9 colour rendering index value	0	
36	eter f and OLI source	Survival factor rounded to the second decimal ( $\geq 0, xx$ )	0. 90	
37	Parar LED light	Lumen maintenance factor rounded to the second decimal (>0.xx)	0.96	
38	Œ	displacement factor (cos $\varphi$ 1) rounded to the second decimal		
39	nd OLI ces:	Colour consistency in McAdam ellipses	6. 0	
40	LED a	Claims that an LED light source replaces a fluorescent light source without integrated ballast of a particular wattage.	-	
41	s for lights	If yes then replacement claim (W) (no decimal)		W
42	ameter nains	Flicker metric (Pst LM) rounded to the first decimal		<u>I</u>
43	Par	Stroboscopic effect metric (SVM) rounded to the first decimal		
44		Technical documentation name (in case of light source product)	1	1
	Light source removing instruction name (in case of containing product)		/ T058-T06K1-BN2-S-LIGHT SOURCE REMOVING INSTRUCTION.pdf	

40	QUALITY LIGHT SOURCE REMOVING INSTRUCTION	Creation date (dd/mm/yyyy) :	08/08/2023
		Last update date (dd/mm/yyyy) :	08/08/2023
-	Supplier's name or trade mark	INSPIRE	
matior	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN	
al infor	Model Identifier - Luminaire Supplier reference	T058-T06K1-WV2-S T058-T06K1-NV2-S T058-T06K1-BN2-S	
Gener	Light sources maker model	T058-T06K1-WN2-S-LS	

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	Pry open the connecting buckle between the upper cylinder body and the lower cylinder body and remove the upper cylinder body		straight screwdriver
Step 2	Rotate the thermal housing counterclockwise to remove the rotating ring, reflective cover and diffusion plate		by hand
Step 3	Remove the press tie		cross screwdriver
Step 4	Remove the screw that holds the light source		cross screwdriver
Step 5	Take the light out		by hand
Step 6			