		JALITY PRODUCT INFORMATION SHEET (ANNEX 5)		
_			Last update date (dd/mm/yyyy) :	08/08/2023
1	tion	Supplier's name or trade mark	ADEO Services	
2	тотша	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS00001	, 59790 RONCHIN
3	General information	Model Identifier - Luminaire Supplier reference	T058-T06K1-WN2-S	
4	Gen	Light sources maker model	T058-T06K1-WN2-S-LS	
5		Date of placement on the market	24/09/2023	
6		Lighting technology used:	LED	
7		Light source cap type (or other electric interface)	/	
8		Non-directional (NDLS) or directional (DLS):	NDLS	
9	rce:	Mains (MLS) or non-mains (NMLS):	NMLS	
10	Type of light source:	Connected light source (CLS):	по	
11	of lig	Colour-tuneable light source:	по	
12	Туре	Envelope:	no	
13	-	High luminance light source:	по	
14		Anti-glare shield:	no	
15		Dimmable:	only with specific dimmers	
16		Energy consumption in on-mode (kWh/1000 h)	4	KWh/1000h
17		Energy efficiency class	D	
18		Useful luminous flux (Φuse), indicating if it refers to the flux in a sphere (360°), in a wide cone (120°) or in a narrow cone (90°),	5501m	360
19		a sphere (300), in a wide cone (120) or in a harrow cone (90), Correlated colour type	steps	
20		Correlated colour temperature, rounded to the nearest 100 K, or the	2700/4000	K
21		range of correlated colour temperatures, rounded to the nearest 100 K, $On\text{-mode}$ power (P_{co}) , expressed in W and rounded to the first decimal	3. 3	w
22		Standby power (P_{ab}) , expressed in W and rounded to the second decimal	0. 00	w
23	ters:	Networked standby power (Pnet) for CLS, expressed in W and rounded to	0.00	w
24	parameters:	the second decimal Colour rendering index, rounded to the nearest integer, or the range	80	"
25	duct	of CRI-values that can be set Outer dimensions without separate control gear, lighting control parts	00	
26		and nonlighting control parts, if any (millimetre) Height (mm)	90, 00	i _{mm}
27	General		90, 00	÷
_				<u></u>
28		Depth (mm) Spectral power distribution in the range 250 nm to 800 nm, at full-	46. 00	mm
29		load (insert picture of the spectral power distribution + name of picture+extension (.jpeg)	T058-T06K1-WN2-S-spectral pc	wer distribution.
30		Claim of equivalent power	yes	ı
31		If yes, equivalent power (W)	45	W
32		Chromaticity coordinates (x and y)	0.380; 0.380	
33	Parameters directional light sources:	Peak luminous intensity (cd)		cd
4	Parameter direction light sources	Beam angle in degrees (no decimal), or the range of beam angles that can be set		Degrees
15	eter for md OLED sources:	R9 colour rendering index value	0	
36	Parameter for LED and OLED light sources:	Survival factor rounded to the second decimal (>0.xx)	0. 90	
37	Pare LED ligh	Lumen maintenance factor rounded to the second decimal (>0.xx)	0.96	
18	ED	displacement factor (cos $\phi 1$) rounded to the second decimal		
19	and OLED rces:	Colour consistency in McAdam ellipses	6. 0	
0	E S	Claims that an LED light source replaces a fluorescent light source without integrated ballast of a particular wattage.	-	
11	's for light	If yes then replacement claim (W) (no decimal)		W
12	Parameters mains li	Flicker metric (Pst LM) rounded to the first decimal		•
13	oar,	Stroboscopic effect metric (SVM) rounded to the first decimal		
_	1	Sechnical documentation name (in case of light source product)	,	1
4				

Δ	adeo QUALITY	Creation date (dd/mm/yyyy) :	08/08/2023			
	LIGHT SOURCE REMOVING INSTRUCTION					
		Last update date (dd/mm/yyyy) :	08/08/2023			
-	Supplier's name or trade mark	INSPIRE				
information	Supplier's address	ADEO Services, 135 rue Sadi Carnot - CS00001, 59790 RONCHIN				
	Model Identifier - Luminaire Supplier reference	7058-706K1-WN2-S 7058-706K1-NN2-S 7058-706K1-BN2-S				
General	Light sources maker model	T058-T06K1-WN2-S-LS				

Instructions on how to remove lighting control parts and/or non-lighting parts, if any, or how to switch them off or minimise their power consumption during light source testing

	Explaination of the step	Pictures	Tools
Step 1	Pry open the connecting buckle between the upper cylinder body and the lower cylinder body and remove the upper cylinder body		straight screwdriver
Step 2	Rotate the thermal housing counterclockwise to remove the rotating ring, reflective cover and diffusion plate		by hand
Step 3	Remove the press tie		cross screwdriver
Step 4	Remove the screw that holds the light source		cross screwdriver
Step 5	Take the light out		by hand
Step 6			